

ASSEMBLING INSTRUCTIONS

ITEM 6525

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD
TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	H2178
	STOPPER WITH PIN	1 PC
	EURO BOLT	4 PCS
	HOUSING D-15/12.5MM	4 PCS
	SCREW CAP	10 PCS
	WOOD DOWEL M8 X 25	16 PCS
	SCREW #9 X 1 1/2"	10 PCS
	ADJUSTABLE SHELF STUD	8 PCS
	SCREW M3 X 20	6 PCS
	CORNER BLOCK	6 PCS
	LEG STUD	5 PCS
	HINGES	4 PCS
	SCREW M3.5 X 14	18 PCS
	HANDLE	2 PCS
	SCREW PAN HEAD #6 X 22	4 PCS
	WEBBING	1 PC
TOOLS REQUIRED :		
	SCREW DRIVER	
STEP 2		HAMMER
<p>WOOD DOWEL M8 X 25</p>		
STEP 3	<p>DETAIL A</p> <p>EURO BOLT</p> <p>SCREW M3.5 X 14</p> <p>DETAIL B</p> <p>STOPPER WITH PIN</p> <p>DETAIL B</p>	
STEP 4	<p>DETAIL A</p> <p>DETAIL B</p> <p>SCREW M3.5 X 14</p> <p>SCREW PAN HEAD #6 X 22</p> <p>HINGES</p> <p>DETAIL A</p> <p>HANDLE</p> <p>DETAIL B</p>	
STEP 5	<p>SCREW #9 X 1 1/2"</p>	
STEP 6	<p>SCREW #9 X 1 1/2"</p> <p>DETAIL A</p> <p>LEG STUD</p>	
STEP 7	<p>SCREW M3 X 20</p>	
STEP 8	<p>DETAIL A</p> <p>HOUSING D-15/12.5MM</p> <p>TURN TO LOCK</p>	
STEP 9	<p>ADJUSTABLE SHELF STUD</p> <p>DETAIL A</p>	
STEP 10	<p>DETAIL A</p> <p>CORNER BLOCK</p> <p>SCREW M3 X 20</p> <p>DETAIL A</p>	
STEP 11	<p>DETAIL A</p> <p>SCREW M3.5 X 14</p> <p>Hinges Adjustment Facilities</p> <p>A.Lateral adjustment by screw adjusting</p> <p>B.Vertical adjustment by the stacking screw adjusting</p> <p>C.Front-to-Back adjustment by the hinges arm mounting plate mounting screw</p>	
STEP 12	<p>SCREW CAP</p> <p>SCREW M3.5 X 14</p> <p>DETAIL A</p> <p>WEBBING</p> <p>DETAIL B</p> <p>DETAIL A</p> <p>Seek advice from qualified trades person on how to attach this to your specific wall.</p>	