

ASSEMBLY INSTRUCTION

9706

Ax5 	Hx1 
Bx1 	Ix4  6x16MM
Cx1 	Jx2  6x25MM
Dx1 	Kx6  6x25MM
Ex1 	Lx1 
Fx1 	Mx2 
Gx4 	

