


ASSEMBLY INSTRUCTION 9320



Ax1



Bx1



Cx1



Dx2



M6x35mm

Ex1



M5x35mm

Fx4



M6x45mm


Gx4



M4



1



2

