





















ASEMBLY INSTRUCTION 2320






A  X30	B  X30	C  X26	D  X4	E  X28	F  X8	G  X8	H  X16	I  X16
J  X1	K  X2	L  X4	 60min 					

①  X1	②  X1	③  X1	④  X2
⑤  X1	⑥  X1	⑦  X1	⑧  X2
⑨  X1	⑩  X1	⑪  LEDX1	 60min 




1




2





3



4



4



6

